



KAPCI
COATINGS

Technical Data Sheet

Issue date January 2024

for professional use only

Prima 8200 Rapid Soft PE Putty

Product description

Prima 8200 is a general-purpose fine pigmented Rapid putty based on polyester resins.


- It provides the best foundation for all Kapci paint systems combining easy application.
- Easy sanding.
- Fast drying.

Substrates

Prima 8200 Rapid PE putty can be applied over variety of substrates such as

- Bare metal.
- Galvanized original car panels.
- Aluminum.
- Glass fibre reinforced plastic (GRP).
- Properly sanded and prepared old finishes in sound conditions.
- Prior to applying Prima 8200 Rapid PE putty the surface should be clean and degreased.

Application



Mixing ratio by weight:

100:1-3

100% Prima 8200 PE Putty

1-3% Kapci PE Putty Hardener

Pot life (working time) of the mixture is 3-4min/ 20°C.



Application:

- Apply by a metal knife. (For edges or curve surfaces use a plastic knife).
- For deep filling, apply in several layers allowing drying between the layers (No sanding in-between is required).



Drying time at 20°C:

Dry to sand: 20 min

The drying time and pot life of a PE putty mixed with the putty hardener will considerably depend on temperature and the amount of the hardener used.

"At lower temperature add 2-3 % of the hardener, at higher temperature add 1%."

IMPORTANT NOTE: These TDS are for information purposes only without any obligation as we do not have control over the quality and conditions of the surface or application.



KAPCI
COATINGS



IR Drying:

Short wave*: 4-6 min

*Guideline for short wave IR equipment. Refer to the IR equipment manufacturer's instruction for sets-up.



Machine dry sanding:

The following grades of sanding papers and steps are recommended:
P80-P120 and finish with P180



Manual dry sanding:

The following grades of sanding papers and steps are recommended:
P80-P120 and finish with P180

General notes

Recoatible

Prima 8200 is recoatable after sanding. For maximum durability apply Kapci 2K Epoxy primer over bare metal before applying Prima 8200 PE Putty.

Other tips

- Mix carefully PE Putty with the hardener to avoid forming of air bubbles in the mixture.
- For long-lasting anticorrosion protection over large surfaces, it is recommended to apply Kapci 2K Epoxy primer over bare metal surfaces before applying PE Putty.
- For small surfaces/damages, PE Putty can be applied over well sanded and degreased bare steel, aluminum, and galvanized steel (original OEM car panels). Use appropriate sanding papers for each surface.
- Do NOT apply PE Putty over 1K etch primers, 2K wash primers, and thermoplastic acrylic paints.
- PE Putty can be applied over 2K Epoxy primers and underneath of 1K Etch Primers and 2K Wash Primers.
- Add 1-3% of PE Putty hardener. Do NOT add less or more the hardener than recommended. The use of too much (more than 3%) or too little (less than 1%) of the hardener can cause a problem of bleaching/staining.
- Do NOT apply paints (2K topcoats, basecoats, etc.) directly over 2K PE putties.
- Do NOT sandwich PE putty between two layers of topcoats.
- Wet sanding of PE putties is NOT recommended.
- In colder conditions, the warming (infrared or oven) of panels can assist in curing prior to applying of 2K PE putties.
- After applying PE putties clean all used tools with strong solvents immediately (e.g., NC thinners).

IMPORTANT NOTE: These TDS are for information purposes only without any obligation as we do not have control over the quality and conditions of the surface or application.



KAPCI
COATINGS

VOC (2004/42/EC)

2004/42/II B(b) (250)230

The EU limit value for this product (product category: IIB.b) in ready for use form is maximum 250 g/liter of VOC.

The VOC content of this product in ready for use form is maximum 230 g/liter.

Health and Safety

1. For full Health and Safety information please refer to Material Safety Data Sheet (MSDS).
2. Observe the precautionary notices displayed on the container.
3. Goggles and suitable protective equipment must be worn while using these products.
4. Good ventilation must be provided in the working environment.