



**KAPCI**  
COATINGS

## Technical data Sheet

Issue date January 2025

for professional use only

# Kapci 2200 Polyester clear sealer

## Product description

Kapci 2200 is a paraffin-free Polyester transparent sealer used for the protection of furniture, wooden articles, and interior woodwork. It has excellent filling and sanding properties, good leveling, and high build. It is recommended for MDF and chipboards in combination with polyurethane finishes where high quality surface treatment is required.

Theoretical coverage: 4-6 m<sup>2</sup>/kg per a coat

## Products for application

Kapci 2200 PE Clear Sealer

Kapci 2210 Accelerator

Kapci 2215 Catalyst

Kapci 2220 Thinner

## Substrate and surface preparation


Kapci 2200 is designed for application over different types of wooden substrate and is particularly recommended for MDF and chipboards in conjunction with polyurethane finishes.

For obtaining optimum results, it is recommended to apply Kapci 2100 Polyurethane Insulator prior to applying Kapci 2200.

In case of applying Kapci 2200 over porous and resinous types of wood (rosewood, teakwood, Mansonia, etc.), the use of the insulator is required. The insulator must be left to dry for 2-3 hours before the application of Kapci 2200 PE Clear Sealer.

Sand the surface of solid wood with P80-P120 grit paper. For MDF, plywood and veneer, use finer grit paper P150 or P180. Blow off dust and degrease the surface.

## Application



PE Sealer	Accelerator:	Catalyst:	PE Thinner:
Kapci 2200	Kapci 2210	Kapci 2215	Kapci 2220
100	2	2	20-30%

Note: Mix Kapci 2200 sealer with Kapci 2210 accelerator prior to adding Kapci 2215 catalyst, then add Kapci 2220 Thinner. Do not mix together accelerator Kapci 2210 with catalyst Kapci 2215.  
Pot life: 15 minutes.

**IMPORTANT NOTE:** These TDS are for information purposes only without any obligation as we do not have control over the quality and conditions of the surface or application.



**KAPCI**  
COATINGS



Apply 2 single coats.

	Spray Nozzle	Inlet pressure	Atomization pressure
Compliant	2.5	2 bars (26- 29 psi)	
HVLP	2.5	2 bars (26- 29 psi)	0.7bar (8-10 psi)
Conventional	2.5	3-3.5 bar (45-50 psi)	

Note: Refer to the spray gun manufacturer's recommendation.



Dry to sand: Next day



Sand with P220 grit paper followed with P320 and finish with P500

### Precautions

As polyesters products are more difficult to use than conventional paints, so precautions and care need to be taken prior to and during the application:

1. Extreme care should be taken when measure catalyst. Do not add less or more catalyst as it will adversely affect the final result.
2. Follow the mixing instructions and order of adding of the mixing components. The accelerator and the catalyst must not be mixed directly with each other!
3. Ensure correct storage and handling of the accelerator and the catalyst. They are inflammable in direct contact.
4. Avoid storage in hot conditions.
5. Be aware of short pot life and short shelf life of the product.

### Other tips

Practical coverage depends on several factors including shape, roughness and porosity of the object to be painted, spraying equipment used, application methods, application conditions, film thickness, etc.

### Shelf life

1 year from production date stored in original packaging at normal conditions. Avoid storage in hot conditions and direct exposure to sun.

### Health and Safety

1. For full Health and Safety information please refer to the Material Safety Data Sheet.
2. Observe the precautionary notices displayed on the container.
3. Good ventilation must be provided in the working environment.

**IMPORTANT NOTE:** These TDS are for information purposes only without any obligation as we do not have control over the quality and conditions of the surface or application.